## Issue during update process

In case you are experiencing issues while the software wants to do an update, please close the application and follow these steps:

- 1. manually delete the shoolQ folder which is located in C:\Program Files\shoolQ by default.
- 2. Visit <u>https://box.shooiq.com</u> and log in with your credentials you also use for the shoolQ software login.

sh	00/10				
Welcome to the shoolQ b2b-Box for retailers. Here you can organize your account and portfolio.					
Username					
Password					
	Forgot your password?				
	LOGIN				

3. Go the the download section and get the latest version of shoolQ.

shoo <sup>va</sup>								
	Downloads	On this page you can access important resources related to corpus.e p	products					
Customers Statistics	Download the latest software and documentation							
<b>K</b>			<b></b>	shoo <sup>lQ</sup> 9.8 x64 version for EVO, Feetbox 30, lightbeam v2 and Vacuum Stations. For lb v1 (single foot) please contact support@corpus=o.com	CONNECTION	DOWNLOAD		
My Portfolio Workbook			Pie 人	shoo <sup>lQ</sup> Box Manual		DOWNLOAD		
			286 人	shoo <sup>lQ</sup> Manual		DOWNLOAD		
			28 人	shoo <sup>lQ</sup> Quickstart		DOWNLOAD		
			<b>255</b>	shoo <sup>lQ</sup> Requirements		DOWNLOAD		
Account Apps Downloads			Ð	shoo <sup>lQ</sup> Remote Support		DOWNLOAD		

4. Do a full installation and start the software

🛃 Setup - shoolQ 9.8.011	_		Х
Komponenten auswählen Welche Komponenten sollen installiert werden?			
Wählen Sie die Komponenten aus, die Sie installieren möchten. Klicken sie bereit sind fortzufahren.	Sie auf "W	/eiter", wei	n
<ul> <li>shooIQ Applikation</li> <li>Hardware Treiber</li> <li>Feetbox EVO</li> <li>Ightbeam2</li> <li>Ightbeam</li> </ul>			
install4j We	iter >	Abbre	chen

Select the hardware driver matching your scanner

- EVO = 2D scanner (no socks required)
- lightbeam2 = 3D scanner (scan both feet at a time + socks required)
- lightbeam = 3D scanner (scan one foot at a time + socks required)