corpus.e

Issue during update process

In case you are experiencing issues while the software wants to do an update, please close the application and follow these steps:

- 1. manually delete the shoolQ folder which is located in C:\Program Files\shoolQ by default.
- 2. Visit <u>https://box.shooiq.com</u> and log in with your credentials you also use for the shoolQ software login.

shoc	DI				
Welcome to the shoolQ b2b-Box for retailers. Here you can organize your account and portfolio.					
Username					
Password					
	Forgot your password?				
LANGUAGE 👻	LOGIN				
LANGUAGE -	LOGIN				



3. Go the the download section and get the latest version of shoolQ.

shoo ^{va}					
	Downloads On this page you can access important resources related to corpuse pro	oducts			
Customers Statistics		Download the latest sol	tware and documentation		Ļ
K			shool ^Q 9.8 x64 version for EVO, Feetbox 3D, lightbeem v2 and Vacuum Stations. For Ib v1 (single foot) pleese contact support@corpus-e.com	CONNECTION	DOWNLOAD
My Portfolio Workbook		Par 人	shoo ^{lQ} Box Manual		DOWNLOAD
		797 人	shoo ^{lQ} Manual		DOWNLOAD
	P3F 人	shoo ^{lQ} Quickstart		DOWNLOAD	
Ö		215 人	shoo ^{lQ} Requirements		DOWNLOAD
Account Apps Downloads	(Ð	shoo ^{lQ} Remote Support		DOWNLOAD

- 4. Install the software by selecting the hardware driver matching your scanner:
 - EVO = 2D scanner (no socks required)
 - lightbeam2 = 3D scanner (scan both feet at a time + socks required)
 - lightbeam = 3D scanner (scan one foot at a time + socks required)

🛃 Setup - shoolQ 9.8.011	_		×
Komponenten auswählen Welche Komponenten sollen installiert werden?			
Wählen Sie die Komponenten aus, die Sie installieren möchten. Klicken Sie sie bereit sind fortzufahren. 	auf "W	eiter", we	nn
🖂 📩 shooIQ Applikation			
🖻 ·· 🔽 📇 Hardware Treiber			
🗄 🖓 🔁 Feetbox EVO			
🖶 🗌 🧰 lightbeam2			
🗄 🖳 🧾 lightbeam			
install4j			
Weite	r >	Abbre	chen